

IPA047096A 470 - 960 MHz, 1 W POWER AMPLIFIER

Key Features



- 470 ~ 960 MHz, 50 Ohm Impedance
- 29 dBm P_{1Db}
- 14 dB Gain
- 1.8:1 VSWR
- 43 dBm IP₃
- Precision Machined Housing
- Single DC Power Supply
- Meet MIL-STD-202g



- VHF & UHF
- PA Driver Amplifiers
- RF Bench Tests
- Fixed Wireless Applications



Absolute Maximum Ratings

Parameters	Units	Ratings	
DC Power Supply Voltage	V	-0.5,16	
RF Input CW Power	dBm	24	
Storage Temperature	°C	-40 ~ +85	
Operating Temperature	°C	-40 ~ +85	

Additional heat sink is required for continuous operation!


Specifications

Summary of the key electrical specifications at 25°C

Index	Testing Item	Symbol	Test Constraints	Min	Nom	Max	Unit
1	Frequency Range	BW	50 Ohm Impedance	470		960	MHz
2	Gain	S ₂₁	470 – 960 MHz	12	14	16	dB
3	Gain Variation	ΔG	470 – 960 MHz		+/- 0.5		dB
4	VSWR	SWR _i	470 – 960 MHz all RF ports		1.8:1	2:1	Ratio
5	Reverse Isolation	S ₁₂	470 – 960 MHz		25		dB
6	Noise Figure	NF	470 – 960 MHz		3.7		dB
7	Output Power 1dB Compression Point	P _{1dB}	470 – 960 MHz	27	29		dBm
8	Output-Third-Order Interception Point	IP ₃	Two-Tone, P _{out} = 10 dBm each, 1 MHz Separation	40	43		dBm
9	Current Consumption	l _{dd}	V _{dd} = +12.0 V		220		mA
10	Power Supply Operating Voltage	V _{dd}		+12		+16	V
11	Operating Temperature	To		-40		+85	°C
12	Thermal Resistance	R _{th.c}	Junction to case			32	°C/W


Functional Block Diagram

Outline, IP-3 Housing



Ordering Information


Model	Connectors			
Number	IN	OUT		
IPA047096A	SMA Female	SMA Female		



Specifications and information are subject to change without notice.



Typical Data



Application Notes:

A. SMA Torque Wrench Selection

Always use a torque wrench with $5 \sim 6$ inch-lb coupling torque setting for mating the SMA cables to the amplifier. Never use torque more than 8 inch-lb wrench for tightening the mating cable to the connector. Otherwise, the permanent damage will occur to the SMA connectors of the amplifier. 8710-1582 (5 inch-lb) is one of the ideal torque wrench choice from Agilent Technology.

B. Mounting the Amplifier

Use three pieces of #2-56 with longer than 9/16" screws for mounting the amplifier on a metal-based chase. Flat and spring washers are needed to prevent the screw loosening during the shock and vibration. Always use the appropriate torque setting of the power screwdriver to mount them.

Specifications and information are subject to change without notice.