

# IHC1700A 0.7 GHz – 2.7 GHz HYBRID COUPLER, 90 DGREE, 10 W CW

### **Key Features**



- Wide Band, 0.7 GHz ~ 2.7 GHz
- Low Insertion Loss, 0.50 dB Typ.
- High Isolation, 18 dB min
- Excellent VSWR 1.22:1 Typ.
- 90 Degree Hybrid, SMA Connector
- Precision Machined Housing
- Single DC Power Supply
- Meet MIL-STD-202g



- Balance Wide Band Power Amplifier
- LTE
- Land Radio
- RF Bench Tests
- Mobile Base Station Applications

# **Absolute Maximum Ratings**

Parameters	Units	Ratings
Input Power(at Port 1) CW	W	10
Storage Temperature	°C	-40 ~ +85
Operating Temperature	°C	-40 ~ +85


Operation of this device beyond any one of these parameters may cause permanent damage.

# Specifications


Summary of the key electrical specifications at 25°C

Index	Testing Item	Symbol	Test Constraints	Min	Тур	Max	Unit
1	Frequency Range	BW	50 Ohm Impedance	0.7		2.7	GHz
2	Insertion Loss	S <sub>21</sub>	0.7 – 2.7 GHz, above 3 dB		0.5	1.3	dB
3	VSWR	SWR <sub>i</sub>	0.7 – 2.7 GHz , all Ports		1.22:1	1.5:1	Ratio
4	Isolation	S <sub>23</sub>	0.7 – 2.7 GHz, 50 Ohm Load at Port C	18	20		dB
5	Amplitude Unbalance	$S_{21} - S_{31}$	0.7 – 2.7 GHz		0.2	0.8	dB
6	Phase Offset	$S_{21} - S_{31}$	0.7 – 2.7 GHz	85	90	95	Deg
7	Power Handling	P <sub>MAX</sub>	0.7 – 2.7 GHz, CW			10	W
8	Operating Temperature	To		-40		+85	°C

# **Functional Block Diagram**



# **Outline, IP-1 Housing**



## **Ordering Information**

Model	Connectors		
Number	IN	OUT	
IHC1700A	SMA Female	SMA Female	

Specifications and information are subject to change without notice.


Fax: +86 591 87303613 E-mail: sales

1/2



2/2

Typical Data



## **Application Notes:**

#### A. SMA Torque Wrench Selection

Always use a torque wrench with  $5 \sim 6$  inch-lb coupling torque setting for mating the SMA cables to the amplifier. Never use torque more than 8 inch-lb wrench for tightening the mating cable to the connector. Otherwise, the permanent damage will occur to the SMA connectors of the amplifier. 8710-1582 (5 inch-lb) is one of the ideal torque wrench choice from Agilent Technology.

#### B. Mounting the Amplifier

Use three pieces of #2-56 with longer than 9/16" screws for mounting the amplifier on a metal-based chase. Flat and spring washers are needed to prevent the screw loosening during the shock and vibration. Always use the appropriate torque setting of the power screwdriver to mount them.

\*\*\*\*\*

Specifications and information are subject to change without notice.